♦ IO-Link Compatible[®]

Digital Flow Switch Manifold for Water



IP65

Flow adjustment

*1 Only compatible with the integrated display type



Footprint

Max. 85% reduction

Flow switch

Weight

Max. 65% reduction

Needs no piping

* Comparison based on integrated type with existing piping work

Work-hour for installation

Max. 45% reduction

Flow range (Single unit)

0.5 to 4 L/min, 2 to 16 L/min, 5 to 40 L/min

■ Number of stations

1 to 10 stations * Max. 5 stations for flow range symbol 40 (5 to 40 L/min)

		Integr	Remote Type					
Series		Basic type PF3WB series	Straight type PF3WC series	Supply type PF3WS Series	Return type PF3WR Series			
			Piping port	TO SOLO				
Rated flow	range [L/min]	0.5 to 4, 2 to 16, 5 to 40						
Po	ort size	3/8 (Up to 4 L/min), 1/2 (Up to 16 L/min), 3/4 (Up to 40 L/min)						
	Flow switch	•	•	_	•			
Unit components	Stop valve	•	•	•	•			
	Flow adjustment valve	•	•	•	•			




Integrated type and Remote type. Select the flow switch according

Integrated Type


Basic type PF3WB

Space can be saved by integrating the supply and return in one unit.






Straight type PF3WC




to your requirements.


Remote Type

Free layout is possible by separating the supply and return unit.










- *2 Fluid temperature can be displayed only when the digital flow switch with a temperature sensor is selected.
- *3 Sub screen can be turned off.
 - Mode display can be selected for IO-Link compatible type.

- Fluid temperature: 0 to 90°C
- Ethylene glycol aqueous solution can be used.
- Non-grease

IO-Link Compatible

Supports the IO-Link communication protocol



Configuration File (IODD File*1)

- Manufacturer
- Product part no.
- Set value

IODD is an abbreviation of IO Device Description. This file is necessary for setting the device and connecting it to a master. Save the IODD file on the PC to be used to set

the device prior to use.



IO-Link is an open communication inter-

IO-Link Compatible Device: **Digital Flow Switch for Water**

Device settings can be set by the master

- Threshold value
- Operation mode, etc.

Read the device data.

- Switch ON/OFF signal and analog value
- Device information:
- Manufacturer, Product part number, Serial number, etc.
- Normal or abnormal device status
- Cable breakage

IO-Link Master

Implement diagnostic bits in the process data.

The diagnostic bit in the cyclic process data makes it easy to find problems with the equipment. It is possible to find problems with the equipment in real time using the cyclic (cycle) data and to monitor such problems in detail with the noncyclic (aperi-


Process Data

Bit offset	Item	Note
0	OUT1 output	0: OFF 1: ON
1	OUT2 output	0: OFF 1: ON
8	Diagnosis (flow rate)	0: OFF 1: ON
9	Diagnosis (temperature)	0: OFF 1: ON
15	Diagnosis (error)	0: OFF 1: ON
16 to 31	Measured temperature value	Signed 16 bit
32 to 47	Measured flow rate value	Signed 16 bit

Application Example

For the predictive maintenance of cooling water problems

Monitors flow rate and temperature's "switch ON/OFF signals" and "analog values" to determine the cooling status The process and cooling status can be compared.





Bit offset	47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	32
Item		Measured flow rate value (PD)														
Bit offset	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
Item	Meası	Measured temperature value (PD) * The area is not used when the product without temperature sensor is selected.														
Bit offset	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Item	Error		Re	servat	ion		Temperature	Flow rate			Reser	vation			OUT2	OUT1
	Diagnosis	Diagnosis Diagnosis					Switch	output								

Display function

Displays the output communication status and indicates the presence of communication data










Operation and Display

Communication with master	IO-Link status indicator light	Status			Screen display*2	Description
	* 1		_	Operate	ModE ofE	Normal communication status (readout of measured value)
			Normal	Start up		At the start of communication
			~	Preoperate	MadE PrE	At the start of communication
Yes	2 / 2 ×1	IO-Link mode	Abnormal	Version does not match	Er 15	The IO-Link version does not match that of the master. The master uses version 1.0.
	(Flashing)			Lock	ModE Lo[Backup and restore required due to data storage lock.
No				Communication disconnection	ModE oPE ModE Strt ModE PrE	Normal communication was not received for 1 second or longer.
	OFF	SIO mod		ode	ModE 510	General switch output

^{*1} In IO-Link mode, the IO-Link indicator will be ON or flashing. *2 When the lower line (sub screen) is set to mode display




Parts Descriptions and Functions (Integrated Type / Basic Type Construction)



CONTENTS

Digital Flow Switch Manifold for Water PF3WB/C/S/R Series



	negrated type Digital Flow Switch Marinold for Water Dasic Type	
)	F3WB Series	
	How to Order ····	· p. 7
r	ntegrated Type Digital Flow Switch Manifold for Water Straight Ty	ре
)	F3WC Series	
	How to Order	· p. 8
	Bigliol Floor Collab Magifold Con Water Co.	
	temote Type Digital Flow Switch Manifold for Water Supply Type	
•	F3WS Series	_
	How to Order	· р. 9
=	emote Type Digital Flow Switch Manifold for Water Return Type	
	F3WR Series	
	How to Order ·····	p. 10
		ρ σ
	Table 1 Return Unit: Flow Switch Output Specifications	p. 11
	Table 2 Return Unit: Flow Switch Unit Specifications	p. 11
	Manifold Common Specifications	-
	Integrated Display Specifications: PF3W7 Series	
	Integrated Display: Temperature Sensor Specifications	
	Remote Sensor Unit Specifications: PF3W5 Series	
	Remote Sensor Unit: Temperature Sensor Specifications	-
	Set Flow Range and Rated Flow Range	•
	Analog Output	•
	Operating Pressure and Proof Pressure	-
	Measurable Range for Ethylene Glycol Aqueous Solution (Reference Value)	
	Flow Characteristics Per Station (Reference Value)	
	Wetted Parts Construction	-
	Disclaimer for Usage of the Replacement Unit	•
	Internal Circuits and Wiring Examples	
	Dimensions (Front View/Mounting Hole Position)	-
	Dimensions (Side View)	
		•
	Function Details	p. 25
	Reference Data ·····	p. 27
	Safety Instructions Back	cover




Integrated Type Digital Flow Switch Manifold


for Water Basic Type

PF3WB Series




How to Order






Manifold type



2 System


	_							
\setminus	Symbol		Stations	Flow range				
	Зу	IIIDOI	Stations	04	20	40		
		01	1 station	•	•	•		
		02	2 stations	•	•	•		
		03	3 stations	•	•	•		
/pe		04	4 stations	•	•	•		
ld ty	В	05	5 stations	•	•	•		
Manifold type	Р	06	6 stations	•	•	_		
Ma		07	7 stations	•	•	_		
		08	8 stations	•	•			
		09	9 stations	•	•			
		10	10 stations	•	•			

Main piping



4 Main piping/Attachment thread type

Nil	Rc
N	NPT
F	G*1




*1 ISO 228 compliant

5 Supply unit components

Symbol	Nil	S	Р	W
Flow adjustment valve	_	•	_	•
Stop valve	_	_	•	•

- The flow switch is not applicable for the supply unit.
- This flow adjustment valve is not suitable for applications which require constant adjustment or stopping of flow.
- The stop valve of this product is not suitable for applications which require adjustment of flow rate.

6 Return unit Flow switch type



Return unit Rated flow range (Flow range)

(
Symbol	Rated flow range (Flow range)			
04	0.5 to 4 L/min			
20	2 to 16 L/min			
40	5 to 40 L/min			

8 Return unit components

	<u> </u>			
Symbol		S	Р	W
Flow adjustment valve	_	•	_	•
Stop valve		_	•	•

- Flow switch is installed on the return unit. (Example shows the integrated display type.)
- * This flow adjustment valve is not suitable for applications which require constant adjustment or stopping of flow.
- The stop valve of this product is not suitable for applications which require adjustment of flow rate.

Return unit: Lead wire for flow switch (Option)

Nil	With lead wire with M8 connector (3 m)	3
N	Without lead wire with M8 connector	
Q	With M12-M8 conversion lead wire (0.1 m)*2	

- *2 A cable (3 m) with an M12 connector is also available separately. For details, refer to the Web Catalog.
- Lead wires for the flow switch will be included with the product.

Supply/Return unit

Port size

Symbol	Port size	Rated flow range (Flow range)				
	3120	04	20	40		
03	3/8	•	△*1	_		
04	1/2	_	•	△*1		
06	3/4		_	•		

*1 Made to order

Return unit Flow switch output specifications Refer to Table 1 on page 11. Return unit Flow switch unit specifications Refer to Table 2 on page 11.




Integrated Type Digital Flow Switch Manifold


for Water Straight Type

PF3WC Series




How to Order






Manifold type




2 System

\setminus	Cumahaal		bol Stations	Flow range		
	Эу	IIIDOI	Sidilons	04	20	40
ē	Manifold type	01	1 station	•	•	•
Manifold type		02	2 stations	•	•	•
		03	3 stations	•	•	•
		04	4 stations	•	•	•
		05	5 stations	•	•	•

3 Supply/Return unit layout






- Not applicable for "Closed" of the main piping
- Main piping port is 1

4 Main piping/Attachment thread type

Nil	Rc
N	NPT
F	G*1



*1 ISO 228 compliant

5 Supply unit components

Symbol	Nil	S	Р	W
Flow adjustment valve	_	•	_	•
Stop valve	_	_	•	•

- * The flow switch is not applicable for the supply unit.
- This flow adjustment valve is not suitable for applications which require constant adjustment or stopping of flow.
- The stop valve of this product is not suitable for applications which require adjustment of flow rate.

6 Return unit Flow switch type

5	7
Remote sensor unit	Integrated display

Return unit Rated flow range (Flow range)

Symbol	Rated flow range (Flow range)	
04	0.5 to 4 L/min	
20	2 to 16 L/min	
40	5 to 40 L/min	

Return unit

8 Return unit components

	<u>-</u>			
Symbol	Nil	S	Р	W
Flow adjustment valve		•	_	•
Stop valve	_	_	•	•

- * Flow switch is installed on the return unit. (Example shows the integrated display type.)
- This flow adjustment valve is not suitable for applications which require constant adjustment or stopping of flow.
- * The stop valve of this product is not suitable for applications which require adjustment of flow rate.

Flow switch output	Nil	With lead wire with M8 connector (3 m)
specifications	N	Without lead wire with M8 connector
Refer to Table 1 on page 11.	Q	With M12-M8 conversion lead wire (0.1 m)*

- *2 A cable (3 m) with an M12 connector is also available separately.
- For details, refer to the Web Catalog. Lead wires for the flow switch will be included with the product.

9 Supply/Return unit Port size

1 011 3120				
Symbol	Port size		d flow rang	٠ ا
		04	20	40
03	3/8	•	△*1	_
04	1/2	_	•	△*1
06	3/4	_	_	•

*1 Made to order





Return unit Flow switch unit specifications Refer to Table 2 on page 11.



Remote Type Digital Flow Switch Manifold


for Water Supply Type

PF3WS Series




How to Order

Remote type (Supply type)




Manifold type



2 System

Cumbal	Stations	Flow range		
Symbol	Stations	04	20	40
01	1 station	•	•	•
02	2 stations	•	•	•
03	3 stations	•	•	•
04	4 stations	•	•	•
05	5 stations	•	•	•
06	6 stations	•	•	_
07	7 stations	•	•	_
08	8 stations	•	•	_
09	9 stations	•	•	
10	10 stations	•	•	_

3 Main piping



4 Main piping/Attachment thread type

Nil	Rc	Main piping
N	NPT	
F	G*1	Attachment\

*1 ISO 228 compliant

5 Supply unit components

Symbol	Nil	S	Р	W
Flow adjustment valve	_	•	_	•
Stop valve	_	_	•	•

- * The flow switch is not applicable for the supply unit.
- * This flow adjustment valve is not suitable for applications which require constant adjustment or stopping of flow.
- * The stop valve of this product is not suitable for applications which require adjustment of flow rate.

6 Rated flow range (Flow range)

(i low range)		
Symbol	Rated flow range (Flow range)	
04	0.5 to 4 L/min	
20	2 to 16 L/min	
40	5 to 40 L/min	

Supply unit port size

Symbol	Port size	Rated flow ran (Flow range)		٠ ا
	3126	04	20	40
03	3/8	•	△*1	_
04	1/2	_	•	△*1
06	3/4	_	_	•

piping is 1 inch.

*1 Made to order

Remote Type Digital Flow Switch Manifold


for Water Return Type

PF3WR Series




How to Order

Remote type (Return type)




Manifold type



2 System

Symbol	Stations	Flow range		
Symbol	Stations	04	20	40
01	1 station	•	•	•
02	2 stations	•	•	•
03	3 stations	•	•	•
04	4 stations	•	•	•
05	5 stations	•	•	•
06	6 stations	•	•	_
07	7 stations	•	•	_
08	8 stations	•	•	_
09	9 stations	•	•	
10	10 stations	•	•	_

Main piping



4 Main piping/Attachment thread type

Nil	Rc	Main piping
N	NPT	
F	G*1	Attachment

*1 ISO 228 compliant

5 Flow switch type

5	7
Remote sensor unit	Integrated display

6 Rated flow range (Flow range)

Symbol	Rated flow range (Flow range)
04	0.5 to 4 L/min
20	2 to 16 L/min
40	5 to 40 L/min

7 Return unit components

Symbol	Nil	S	Р	W
Flow adjustment valve	_	•	_	•
Stop valve	_	_	•	•

- * Flow switch is installed on the return unit. (Example shows the integrated display type.)
- * This flow adjustment valve is not suitable for applications which require constant adjustment or stopping of flow.
- * The stop valve of this product is not suitable for applications which require adjustment of flow rate.

8 Return unit port size

Symbol	Port size	Rated flow range (Flow range)		
	Size	04	20	40
03	3/8	•	△*1	_
04	1/2	_	•	△*1
06	3/4	_	_	•

*1 Made to order

9 Flow switch output specifications
Refer to Table 1 on page 11.

piping is 1 inch.

Lead wire for flow switch (Option)

Nil	With lead wire with M8 connector (3 m)
N	Without lead wire with M8 connector
Q	With M12-M8 conversion lead wire (0.1 m)*2

- *2 A cable (3 m) with an M12 connector is also available separately.
- For details, refer to the Web Catalog.
- * Lead wires for the flow switch will be included with the product.

Flow switch unit specifications
Refer to Table 2 on page 11.

Table 1 Return Unit: Flow Switch Output Specifications

		OUT4		ITO	
_		OUT1	OL.	JT2	Temperature
Туре	Symbol	Flow rate/ Temperature*5	Flow rate	Temperature	sensor
	1	Analog 1 to 5 V	_	_	None
Remote	2	Analog 4 to 20 mA	_	_	None
sensor unit	1T	Analog 1 to 5 V	_	Analog 1 to 5 V	Yes
	2T*1	Analog 4 to 20 mA	_	Analog 4 to 20 mA	165
	Α	NPN	NPN	_	
	В	PNP	PNP	_	
	С	NPN	Analog 1 to 5 V	_	
	D	NPN	Analog 4 to 20 mA	_	None
	E	PNP	Analog 1 to 5 V	_	None
	F	PNP	Analog 4 to 20 mA	_	
Integrated	G*1	NPN	External input*2	<u> </u>	
display	H *1	PNP	External input*2	_	
	ΑT	NPN	(NPN) ¢	⇒* ³ NPN	
	BT	PNP	(PNP) ⇔*3 PNP		Yes
	CT	NPN	(Analog 1 to 5 V) \Leftrightarrow *3 Analog 1 to 5 V		
	DT	NPN	(Analog 4 to 20 mA) ←	⇒*3 Analog 4 to 20 mA	165
	ET	PNP	(Analog 1 to 5 V) ¢	⇒*3 Analog 1 to 5 V	
	FT	PNP	(Analog 4 to 20 mA) ←	⇒*3 Analog 4 to 20 mA	
	L *1	IO-Link/			
	L	Switch output (N/P)	_		None
	L2*1	IO-Link/	Switch output (N/P)		None
Integrated display	LZ	Switch output (N/P)	Switch ou	tput (14/1)	
(IO-Link compatible*4)	LT	IO-Link/	_	_	
	L 1	Switch output (N/P)	_		Yes
	L2T *1	IO-Link/	Switch output (N/P)		res
		Switch output (N/P)			

- *1 Made to order
- *2 External input: The accumulated value, peak value, and bottom value can be reset.
- *3 For units with temperature sensor, only OUT2 can be set as either temperature output or flow rate output. Setting when shipped is for temperature output.
- *4 Only integrated display type is suitable for IO-Link.
- *5 For symbols "LT" and "L2T" (IO-Link compatible product with temperature sensor), even OUT1 supports temperature output.
- * To use a remote sensor unit in combination with a remote monitor (PF3W3 series), select analog output of 1 to 5 V of flow rate (output symbol "1" or "1T").

Table 2 Return Unit: Flow Switch Unit Specifications

Type	Symbol	Instantaneous flow	Accumulated flow	Temperature
Remote	Nil	L/min	_	°C
sensor unit	G *1	L/min (gal/min)	_	°C (°F)
	M	L/min	L	°C
Integrated	G*1	gal/min	gal	°C
display	F*1	gal/min	gal	°F
	J *1	L/min	L	°F
Integrated display	Nil*1	gal/min	gal	°C
(IO-Link compatible)	M	L/min	L	°C

- *1 Made to order
- * Under the New Measurement Act, units other than SI cannot be used in Japan.
 - Remote sensor unit: Nil
 - · Integrated display: M
- · Integrated display (IO-Link compatible): M

Reference: 1 [L/min] \Leftrightarrow 0.2642 [gal/min] 1 [gal/min] \Leftrightarrow 3.785 [L/min]

°F = 9/5°C + 32

Manifold Common Specifications

	Model	PF3WB	PF3WC	PF3WS	PF3WR
Manifold type		Integrat	ted type	Remote type	
System		1 to 10 stations*1	Supply: 1 to 5 stations Return: 1 to 5 stations	1 to 10 stations*1	
	Rated flow range		0.5 to 4 L/min, 2 to 16	6 L/min, 5 to 40 L/min	
Unit	Supply unit components	Flo	w adjustment valve, Stop va	lve	_
	Return unit components	Flow switch, Flow adjus	stment valve, Stop valve	_	Flow switch, Flow adjustment valve, Stop valve
Fluid	Applicable fluid	Water and Ethy	lene glycol aqueous solution	n (with viscosity of 3 mPa·s	[3 cP] or less)*2
riulu	Fluid temperature		0 to 90°C (No freezi	ng or condensation)	
Pressure	Operating pressure range*3		0 to 1	MPa	
specifications	Proof pressure*3	1.5 MPa			
specifications	Pressure loss		Refer to the "Pres	sure Loss" graph.	
Environmental	Enclosure		IP	65	
resistance	Operating temperature range		0 to 50°C (No freezi	ng or condensation)	
resistance	Operating humidity range		Operation, Storage: 35 to 8	5% R.H. (No condensation)	
Standards		CE marking (EMC directive/RoHS directive)			
Wetted parts material*4		PPS, Stainless steel 304, FKM			
		Non-grease			
Dout oize*5	Main piping	1			
Port size*5 Attachment		3/8, 1/2, 3/4			

- *1 Max. 5 stations when the flow rate symbol for the supply/return unit is 40 (5 to 40 L/min)
- *2 Refer to the graph of measurable range for ethylene glycol aqueous solution on page 14. Measurement is possible as long as the fluid does not corrode the wetted parts and viscosity is 3 mPa·s (3 cP) or less. Be aware that water leakage may occur due to internal seal shrinkage or swelling depending on the type of fluid.
- *3 The operating pressure range and proof pressure may change according to the fluid temperature. Refer to the graphs on page 14.
- *4 For details, refer to the "Wetted Parts Construction" on page 16.
- *5 When the piping diameter or piping passage is restricted, the specifications may not be satisfied.
- * Products with tiny scratches, marks, or flow switch display color or brightness variations which do not affect the performance of the product are verified as conforming products.

Integrated Display Specifications: PF3W7 Series

For detailed specifications of flow switches, refer to the PF3W series in the Web Catalog or the Operation Manual.

Model	PF3W704	PF3W720	PF3W740		
Detection method		Karman vortex			
Rated flow range	0.5 to 4 L/min	2 to 16 L/min	5 to 40 L/min		
Display flow range	0.35 to 5.50 L/min	1.7 to 22.0 L/min	3.5 to 55.0 L/min		
Display flow range	(Flow under 0.35 L/min is displayed as "0.00")	(Flow under 1.7 L/min is displayed as "0.0")	(Flow under 3.5 L/min is displayed as "0.0")		
Set flow range	0.35 to 5.50 L/min	1.7 to 22.0 L/min	3.5 to 55.0 L/min		
Smallest settable increment	0.01 L/min	0.1 L/min			
Accuracy	Disp	play value: ±3% F.S., Analog output: ±3%	F.S.		
Repeatability		±2% F.S.			
Temperature characteristics	±5% F.S. (25°C standard)				
Power supply voltage	12 to 24 VDC ±10%				
Current consumption	50 mA or less				
Standards and regulations	C	E marking (EMC directive/RoHS directive	e)		

IO-Link Compatible

		<u> </u>			
Model		Model	PF3W704	PF3W720	PF3W740
Accumulated flow range*1		nd flow rango*1	999999999 L		999999999 L
ACI	Accumulated flow range		By 0.1 L		By 1 L
Ħ	Maximu	m applied voltage	30 V (NPN output)		
outpi	Interna	l voltage drop	1.5 V or	less (at load current of	80 mA)
ᄝ	Dolov ti	imo*2		3.5 ms	
당	Delay time*2		Variable from 0 to 60 s/0.01 s increments		
ξ	Output mode Flow rate		Select from Hysteresis, Window comparator, Accumulated output,		
တ်			Accumulated pulse output, Error output, or Switch output OFF modes.		
Power supply voltage	When used as a switch output device		12 to 24 VDC, including ripple (p-p) 10%		
M See	ছুট্ট When used as an		18 to 30 VDC, including ripple (p-p) 10%		
೭	P IO-Link device To to 50 VBG, including hippie (p-p) 10/5		J-p) 10 /8		
Digital filter*3			Select from 0.5 s, 1.0 s, 2.0 s, 5.0 s, 10.0 s, 15.0 s, 20.0 s, or 30.0 s.		
		thstand voltage	250 VAC for 1 minute between external terminals and housing		
Standards and regulations		and regulations	CE marking (EMC directive/RoHS directive)		

- *1 Cleared when the power supply is turned off
 The hold function can be selected. If the 5-minute interval is selected, the life of the memory
 element (electronic parts) is limited to 3.7 million
 times. (If energized for 24 hours, life is calculated
 as 5 minutes x access times (3.7 million) = 18.5
 million minutes = about 35 years.) Therefore, if
 using the hold function, calculate the memory life
 for your operating conditions, and use within this
 life
- *2 Does not include the value of the digital filter
- *3 The response time until the set value reaches 90% in relation to the step input (The response time is 7 s when it is output by the temperature sensor.)

Communication Specifications (IO-Link mode)


Device
V1.1
COM2 (38.4 kbps)
IODD file*1
3.5 ms
Input data: 6 bytes, Output data: 0 byte
Yes
Yes
Yes
131 (0 x 0083)

*1 The configuration file can be downloaded from the SMC website, https://www.smcworld.com

Device ID*1

Mod	el	PF3W704	PF3W720	PF3W740
	L	352	353	354
Output	L2	(0 x 0160)	(0 x 0161)	(0 x 0162)
specification	LT	357	358	359
	L2T	(0 x 0165)	(0 x 0166)	(0 x 0167)

*1 The device ID differs according to each product type (flow range, whether or not a temperature sensor is provided, etc.).




* For wiring, refer to the Operation Manual on the SMC website, https://www.smcworld.com

Integrated Display: Temperature Sensor Specifications

Rated temperature range	0 to 100°C*1
Set/Display temperature range	−10 to 110°C
Smallest settable increment	1°C
Display unit	°C
Display accuracy	±2°C
Analog output accuracy	±3% F.S.
Response time	7 s*2
Ambient temperature characteristics	+5% F.S.

- *1 The rated temperature range refers solely to that of the temperature sensor. The fluid temperature range specification of the flow switch as a whole is 0 to 90°C.
- st2 The response time refers solely to that of the temperature sensor.

Excluding the IO-Link compatible product, only OUT2 supports output related to the temperature sensor.



The OUT2 can be selected from either the output for temperature or flow rate by button operation.



Remote Sensor Unit Specifications: PF3W5 Series

For detailed specifications of flow switches, refer to the PF3W series in the Web Catalog or the Operation Manual.

Model	PF3W504	PF3W520	PF3W540	
Detection method	Karman vortex			
Rated flow range	0.5 to 4 L/min	2 to 16 L/min	5 to 40 L/min	
Accuracy	±3% F.S.			
Repeatability	±2% F.S.			
Temperature characteristics	±5% F.S. (25°C standard)			
Power supply voltage	12 to 24 VDC ±10%			
Current consumption	30 mA or less			
Standards and regulations	CE marking (EMC directive/RoHS directive)			

Remote Sensor Unit: Temperature Sensor Specifications

Rated temperature range	0 to 100°C*1
Analog output accuracy	±3% F.S.
Response time	7 s*2
Ambient temperature characteristics	±5% F.S.


- *1 The rated temperature range refers solely to that of the temperature sensor. The fluid temperature range specification of the flow switch as a whole is **0 to 90°C**.
- *2 The response time refers solely to that of the temperature sensor.

Set Flow Range and Rated Flow Range

⚠ Caution

Set the flow rate within the rated flow range.

The set flow range is the range of flow rate within which setting is possible. The rated flow range is the range within which the sensor specifications (accuracy, etc.) are satisfied. It is possible to set a value outside of the rated flow range if it is within the set flow range. However, the satisfaction of the specifications cannot be guaranteed.



For the PF3W5 series, the display flow range and set flow range are the same as those of the flow monitor PF3W3 series.

Rated flow range Display flow range Set flow range

Analog Output


1 V


Voltage output

Flow rate/Analog output

1.5 V


5 V






Fluid temperature/Analog output

0.6 V	1 V
2.4 mA	4 mA
С	D
5 V	5.4 V
	2.4 mA




Operating Pressure and Proof Pressure


Supply/Return unit components: Nil




Supply/Return unit components: S/P/W



Measurable Range for Ethylene Glycol Aqueous Solution (Reference Value)



Straight Piping Length and Accuracy (Reference Value)



- · The smaller the piping size, the more the product is affected by the straight piping length.
- \cdot Fluid pressure has almost no affect.
- · Low flow rate lessens the effect of the straight piping length.
- Use a straight pipe that is 8 cm or longer in length to satisfy the ±3% F.S. specification.

Flow range: 0.5 to 4 L/min (Symbol 04)

Flow range: 2 to 16 L/min (Symbol 20)

Pressure: 0.3 MPa Piping diameter: ø12 ±10 ±9 Port size: 3/8 (Symbol 03) ±8 (at 16 L/min) Accuracy [%F.S. ±7 ±6 Port size: 1/2 (Symbol 04) (at 16 L/min) ±5 ±4 ±3 ±2 Port size: 3/8 (Symbol 03) ±1 ±0 (at 8 L/min) Straight piping length [cm]

Flow range: 5 to 40 L/min (Symbol 40)

Pressure: 0.3 MPa Piping diameter: ø16 +10 ±9 ±8 Accuracy [%F.S.] ±7 ±6 Port size: 1/2 (Symbol 04) (at 40 L/min)-±5 ±4 ±3 ±2 Port size: 3/4 (Symbol 06) (at 40 L/min) +1 ±0 8 Straight piping length [cm]




Flow Characteristics Per Station (Reference Value)


■ Supply Unit (Without flow switch)

Rated flow range	Unit components			Cv factor
(Flow range)	Symbol	Flow adjustment valve	Stop valve	CV lactor
	Nil	_	<u> </u>	2.04
0.5 to 4 L/min	S	•	_	1.20
(Symbol 04)	Р	_	•	1.65
	W	•	•	1.03
	Nil	_	_	3.31
2 to 16 L/min	S	•	_	1.31
(Symbol 20)	Р	_	•	1.80
	W	•	•	1.11
	Nil	_	_	6.36
5 to 40 L/min	S	•	_	3.57
(Symbol 40)	Р	_	•	2.49
	W	•	•	2.17


Flow range: 0.5 to 4 L/min (Symbol 04) (Reference value)



Flow range: 2 to 16 L/min (Symbol 20) (Reference value)




Flow range: 5 to 40 L/min (Symbol 40) (Reference value)




■ Return Unit (With flow switch) * The flow path of the integrated display type and remote sensor type is common.

Rated flow range	Unit components			Cv factor
(Flow range)	Symbol	Flow adjustment valve	Stop valve	CV lactor
	Nil	_	_	0.50
0.5 to 4 L/min	S	•	_	0.49
(Symbol 04)	Р	_	•	0.50
	W	•	•	0.48
	Nil	_	_	1.79
2 to 16 L/min	S	•	_	1.21
(Symbol 20)	Р	_	•	1.38
	W	•	•	1.05
	Nil	_	_	4.57
5 to 40 L/min	S	•	_	3.11
(Symbol 40)	Р	_	•	2.42
	W	•	•	2.04


Flow range: 0.5 to 4 L/min (Symbol 04) (Reference value)




Flow range: 2 to 16 L/min (Symbol 20) (Reference value)




Flow range: 5 to 40 L/min (Symbol 40) (Reference value)




Wetted Parts Construction




<Main piping cross section>



<Unit cross section> Stop valve fully open



Stop valve fully closed



Component Parts

COII			
No.	Description	Material	Note
1	Attachment	Stainless steel 304	
2	Seal	FKM	
3	Sensor body	PPS	
4	Flow sensor	PPS	
5	Temperature sensor	Stainless steel 304	
6	Temperature sensor body	PPS	
7	Stop valve body	PPS	
8	Stop valve shaft	PPS	
9	Guide	PPS	
10	Flow adjustment valve shaft	Stainless steel 304	

No.	Description	Material	Note
11	Flow adjustment valve cover	PPS	
12	Shaft support	PPS	
13	Flow adjustment valve body	PPS	
14	Main body	PPS	
15	Main piping	Stainless steel 304	
		PPS	Through-hole type
16	Connecting part	Stainless steel 304	No through-hole between the supply/ return unit of manifold type C (Supply unit and return unit are separate.)

Disclaimer for Usage of the Replacement Unit

For the water manifold, a replacement unit is available in order to facilitate maintenance and repairs. Refer to the replacement manual (Document no. PF**-PSY0047) for the replacement unit product numbers, replacement procedures, and instructions.

As the replacement unit is a replacement part for SMC's water manifold, it cannot be used in other products or applications. Therefore, use of parts in other products or applications after the disassembly and reassembly of the manifold when replacing the unit will render the warranty invalid.




Internal Circuits and Wiring Examples

Integrated display


-A(T)

NPN (2 outputs)




-E(T)/F(T)

E(T): PNP + Analog voltage output F(T): PNP + Analog current output




-B(T) PNP (2 outputs)




-G

NPN + External input



-C(T)/D(T)


C(T): NPN + Analog voltage output D(T): NPN + Analog current output



-H

(32.8)

PNP + External input



(3000)

ø4

Lead wire (Option)

Connector pin number Example




Pin no.	Pin name
1	DC (+)
2	OUT2
3	DC (-)
4	OUT1

ZS-40-A Lead wire with M8 connector

(Black) 4

(Blue) 3 М8

4



OUT1

2 (White)

1 (Brown)

Black

- 4-wire type lead wire with M8 connector used for the PF3W□ series
- For wiring, refer to the Operation Manual on the SMC website, https://www.smcworld.com

Lead Wire Specifications Nominal cross AWG 23 section Conductor Approx. 0.7 mm O.D. Material Heat-resistant PVC

(45)

(15)

Approx. 1.1 mm Insulator O.D. Color Brown, White, Black, Blue Sheath Material Heat- and oil-resistant PVC

Finished O.D. ø4


Internal Circuits and Wiring Examples

Integrated display (IO-Link)


-L(T)

When used as a switch output device (When not used as an IO-Link device = When in SIO mode)

NPN setting



PNP setting




When used as an IO-Link device




-L2(T)

When used as a switch output device (When not used as an IO-Link device = When in SIO mode)


NPN setting



PNP setting



When used as an IO-Link device




Remote sensor unit

-1/2

1: Analog voltage output


2: Analog current output



-1T/2T


1T: Analog voltage output (With temperature sensor output)


2T: Analog current output (With temperature sensor output)



Dimensions (Front View/Mounting Hole Position)


Integrated type (Basic type): PF3WB






					[mm]
Flow range	- 1	4	E	3	
[L/min]	Open	Closed	Open	Closed	а
0.5 to 4 (Symbol 04)	33	14	33	14	40
2 to 16 (Symbol 20)	33	14	33	14	40
5 to 40 (Symbol 40)	33	14	33	14	45

Integrated type (Straight type): PF3WC ---------






SMC

[L/min]

5 to 40 (Symbol 40)

Dimensions (Front View/Mounting Hole Position)


Remote type (Supply type): PF3WS -----



01 01 01 01 01 01 01 01 01 01 01 01 01 0	7	55
		-
	т '	'
		+ 38
		<u>@</u>
6.5 6.5	2	-A- •
6.5		
Mounting hole position		

					[mm]
Flow range		4		3	
[L/min]	Open	Closed	Open	Closed	а
0.5 to 4 (Symbol 04)	33	14	33	14	40
2 to 16 (Symbol 20)	33	14	33	14	40
5 to 40 (Symbol 40)	33	14	33	14	45

Remote type (Return type): PF3WR - --------





					[mm]
Flow range		4	E	3	
[L/min]	Open	Closed	Open	Closed	а
0.5 to 4 (Symbol 04)	33	14	33	14	40
2 to 16 (Symbol 20)	33	14	33	14	40
5 to 40 (Symbol 40)	33	14	33	14	45



Dimensions (Side View)


Integrated type (Basic type); PF3WB

Flow range: 0.5 to 4 L/min (Symbol 04) / 2 to 16 L/min (Symbol 20)

Unit components: P (With stop valve) Supply unit

Flow switch: Integrated display (With temperature sensor) Return unit


Unit components: W (With flow adjustment valve and stop valve)



Supply unit Unit components: S (With flow adjustment valve)

Return unit Flow switch: Remote sensor unit (With temperature sensor)

Unit components: None



A: Return Unit Overall Length

Flance accritish to man	Temperature	ГI истана	Dout aire		Unit components		Α		
Flow switch type	sensor	Flow range	Port size	Symbol	Flow adjustment valve	Stop valve	[mm]		
				Nil	_	_	61.9		
	None			S	•	_	61.9		
	None			Р	_	•	95.9		
		0.5 to 4 L/min	3/8	W	•	•	95.9		
		(Symbol 04)	(Symbol 03)	Nil	_	_	72.9		
	Yes					S	•	_	72.9
	res			Р	_	•	106.9		
Remote sensor unit				W	•	•	106.9		
Integrated display				Nil	_	_	65.9		
	None			S	•	_	65.9		
	None			Р	_	•	99.9		
		2 to 16 L/min	3/8 (Symbol 03)	W	•	•	99.9		
		(Symbol 20)	1/2 (Symbol 04)	Nil	_	_	76.9		
	Yes			S	•	_	76.9		
	162			Р	_	•	110.9		
				W	•	•	110.9		

B: Supply Unit Overall Length

Flow range	Port size		Unit components						
Flow range	FUIT SIZE	Symbol	Flow adjustment valve	Stop valve	[mm]				
		Nil	_	_	31.9				
0.5 to 4 L/min	3/8	S	•	_	31.9				
(Symbol 04)	(Symbol 03)	P	_	•	65.9				
		W	•	•	65.9				
		Nil	_	_	35.9				
2 to 16 L/min	3/8 (Symbol 03)	S	•	_	35.9				
(Symbol 20)	1/2 (Symbol 04)	Р	_	•	69.9				
		W	•	•	69.9				




Dimensions (Side View)

Integrated type (Basic type): PF3WB Flow range: 5 to 40 L/min (Symbol 40)

Supply unit Unit components: P (With stop valve)

Return unit Flow switch: Integrated display (With temperature sensor)


Unit components: W (With flow adjustment valve and stop valve)



Supply unit Unit components: S (With flow adjustment valve)

Return unit Flow switch: Remote sensor unit (With temperature sensor)

Unit components: None



A: Return Unit Overall Length

Flow switch type	Temperature	Flow rongo	Port size		Α					
Flow switch type	sensor	Flow range	Port Size	Symbol	Flow adjustment valve	Stop valve	[mm]			
				Nil	_	_	95			
	None		S	•	_	95				
	None			Р	_	•	139			
Remote sensor unit		5 to 40 L/min	1/2 (Symbol 04)	W	•	•	139			
Integrated display		(Symbol 40)	3/4 (Symbol 06)	Nil	_	_	106			
		Yes		S	•	_	106			
res	res			Р	_	•	150			
				W	•	•	150			

B: Supply Unit Overall Length


Elow rongo	Port size		Unit components						
Flow range	FUIT SIZE	Symbol	Flow adjustment valve	Stop valve	[mm]				
		Nil	_	_	51				
5 to 40 L/min	1/2 (Symbol 04)	S	•	_	51				
(Symbol 40)	3/4 (Symbol 06)	Р	_	•	95				
		W	•	•	95				




Dimensions (Side View)

Remote type (Supply type): PF3WS / Integrated type (Straight type): PF3WC Supply side

Unit components: P (With stop valve)



Unit components: S (With flow adjustment valve)




A: Supply Unit Overall Length

A. Supply	Ullit Overal	Lengin								[mm]	
Flow rongo	Port size	l	Jnit component	ts	Α	В	С	D	E	F	
Flow range	Port Size	Symbol	Flow adjustment valve	Stop valve	Α	P		0	=	F	
		Nil	_	_	31.9						
0.5 to 4 L/min	3/8	S	•	_	31.9	141.7	102.6	87.5	127.9	87.5	
(Symbol 04)	(Symbol 03)	Р	_	•	65.9	141.7	102.6	87.5	(Max. 132.9)	67.5	
		W	•	•	65.9	1					
	3/8	Nil		_	35.9				127.9		
2 to 16 L/min	(Symbol 03)	S	•	_	35.9	141.7	102.6	87.5		87.5	
(Symbol 20)	1/2	Р		•	69.9	141.7	102.6	67.5	(Max. 132.9)	87.5	
	(Symbol 04)	W	•	•	69.9	1					
	1/2	Nil		_	51						
5 to 40 L/min	(Symbol 04)	S	•	_	51	1510	444.5	91.3 137.5 (Max. 143	137.5	01.0	
(Symbol 40)	3/4	Р		•	95	151.2	111.5		(Max. 143.2)	91.3	
	(Symbol 06)	W	•	•	95	1					


Dimensions (Side View)

Remote type (Return type): PF3WR / Integrated type (Straight type): PF3WC Return side

Flow switch: Integrated display (With temperature sensor) Unit components: W (With flow adjustment valve and stop valve)



Flow switch: Remote sensor unit (With temperature sensor) **Unit components: None**



A: Return Unit Overall Length

A: Return	Unit C	Overall Len	igth												[mm														
	e			Unit	compon	ents																							
Flow switch type	Temperature sensor	Flow range	Port size	Symbol	Flow adjustment valve	Stop valve	A	В	С	D	E	F	G	Н	ı														
					Nil	_	_	61.9																					
	None			S	•	_	61.9																						
	None			Р	_	•	95.9					107.0																	
		0.5 to 4 L/min	3/8	W	•	•	95.9	132.3	112.9	87.5	102.6	127.9 (Max.	141.7	117.9	102.6														
		(Symbol 04)	(Symbol 03)	Nil	_	_	72.9	102.0	112.9	07.5	102.0	132.9)																	
	Yes			S		_	72.9								102.0)	102.0)		,											
	165			Р	_	•	106.9																						
				W	•	•	106.9																						
				Nil	_	_	65.9																						
	None			S	•	_	65.9																						
Remote	110110	2 to 16 L/min													3/8	Р		•	99.9					127.9					
sensor unit			(Symbol 03)	W	•	•	99.9	132.3	112.9	87.5	102.6			117.9	102.6														
Integrated		(Symbol 20)	1/2	Nil	_	_	76.9	102.0	1	07.0					102.0														
display	Yes		(Symbol 04)		•	_	76.9					'																	
				Р	_	•	110.9																						
				W	•	•	110.9																						
				Nil	_		95																						
	None			S	•	_	95																						
			1/2	P		•	139	140.1 120				137.5			111.5														
		5 to 40 L/min (Symbol 0 (Symbol 40) 3/4			•	•	139		120.7	91.3	110.1	(Max.	151.2	125.7															
			, ,	` ,	` '	` '	` '	` ,		` '	` ,	` '	1 ` ,	(Symbol 40)	(Symbol 40)	` '	` '	·	Nil	_		106	-	-====		1.0.1	143.2)		
	Yes		(Symbol 06)	S	•	_	106																						
				W	_	•	150																						
	I	1		· · · · · · · · · · · · · · · · · · ·			150	1	I	I	l	1	1	1	I														



PF3W□ Series Function Details

Integrated Display: PF3W7 Series

■ Delay time setting (IO-Link compatible type only)

The time from when the instantaneous flow reaches the set value to when the switch output operates can be set. Setting the delay time can prevent the switch output from chattering.

The total switching time is the switch operation time and the set delay time.

(Default setting: 0 s)

0.00 s
0.05 to 0.1 s (increment of 0.01 s)
0.1 to 1.0 s (increment of 0.1 s)
1 to 10 s (increment of 1 s)
20 s
30 s
40 s
50 s
60 s

■ Output operation

The output operation can be selected from the following:
Output (hysteresis mode and window comparator mode)

Output (hysteresis mode and window comparator mode) corresponding to instantaneous flow rate, output corresponding to accumulated flow, or accumulated pulse output.

 At the time of shipment from the factory, it is set to hysteresis mode and normal output.

■ Display color

The display color can be selected for each output condition. The selection of the display color provides visual identification of abnormal values.

Green for ON, Red for OFF
Red for ON, Green for OFF
Red all the time
Green all the time

■ Response time (Digital filter)

The response time (digital filter) can be set to suit the application. Setting the response time (digital filter) can reduce chattering of the switch output and flickering of the analog output and the display. The response time indicates when the set value is 90% in relation to the step input.

* The temperature sensor output is fixed to 7 s.

Response time	Applicable model		
(Digital filter)	IO-Link non-compatible	IO-Link compatible	
0.5	•	•	
1.0 (Default)	•	•	
2.0	•	•	
5.0	_	•	
10.0	_	•	
15.0	_	•	
20.0	_	•	
30.0	_	•	

■ External input function (IO-Link non-compatible type only)-

This function can be used only when the optional external input is present. The accumulated flow, peak value, and bottom value can be reset remotely. **Accumulated value external reset:** A function to reset the accumulated flow value when an external input signal is applied.

In accumulated increment mode, the accumulated value will reset to and increase from zero.

In accumulated decrement mode, the accumulated value will reset to and decrease from the set value.

* When the accumulated value is stored to memory, every time the accumulated value external reset is activated, the memory (EEPROM) will be accessed. Take the life time of the memory device into consideration before using this function.

Peak/Bottom value reset: Peak and bottom value are reset.

■ Forced output function

The output is turned on/off in a fixed state when starting the system or during maintenance. This enables the confirmation of wiring and prevents system errors due to unexpected output.

For the analog output type, when ON the output will be 5 V or 20 mA, and when OFF, it will be 1 V or 4 mA.

For IO-Link compatible series, diagnostic bit (error, flow rate and temperature), process data (PD) flow and temperature measurement can be checked.

* Also, an increase or decrease of the flow and temperature will not change the on/off status of the output while the forced output function is activated.


■ Accumulated value hold

The accumulated value is not cleared even when the power supply is turned off. The accumulated value is memorized every 2 or 5 minutes during measurement and continues from the last memorized value when the power supply is turned on again.

The life time of the memory device is 1 million access times (3.7 million access times for the IO-Link compatible type). Take this into consideration before using this function.

■ Analog output free range function (IO-Link non-compatible type only) —

This function allows a flow that generates an output of 5 V or 20 mA to be changed. (This function is not available for the analog output to the temperature.) This function is available if the analog output type is used. The value can be changed between 10% of the maximum value of the rated flow and the maximum value of the display range.



■ Display

Display is different for IO-Link compatible type.



Sub screen (6-digit) Unit display

IO-Link non-compatible

■ Power-saving mode

The display can be turned off to reduce power consumption. In power-saving mode, only decimal points blink.

If any button is pressed during power-saving mode, the display is recovered for 30 seconds to check the flow, etc.

■ Setting of security code:

The user can select whether a security code must be entered to release the key lock. At the time of shipment from the factory, it is set such that a security code is not required.



Sub screen (9-digit) Unit display

IO-Link compatible

■ Peak/Bottom value display

The maximum (minimum) flow rate is detected and updated from when the power supply is turned on. In peak (bottom) value display mode, this maximum (minimum) flow rate is displayed.

■ Key-lock function

Prevents operation errors such as accidentally changing setting values



FLOW indicator

POWER indicator

Integrated Display: PF3W7 Series

■ Error display function -

When an error or abnormality arises, the location and contents are displayed.

D: 1:	5		A .:	Applicable model	
Display	Description	Contents	Action	IO-Link non-compatible	IO-Link compatible
Er 1	OUT1 over current error	The switch output (OUT1) load current of 80 mA or more flows.	Turn the power OFF and remove the cause of the over current. Then turn	•	•
Er 2	OUT2 over current error	The switch output (OUT2) load current of 80 mA or more flows.	the power ON again.	•	•
HHH	Instantaneous flow error	The flow has exceeded the upper limit of the display flow range.	Decrease the flow rate.	•	•
(Alternately displays [999] and [999999]	Accumulated flow error	The accumulated flow has exceeded the accumulated flow range.	Reset the accumulated flow.	•	
999999 (Flashing)	Accumulated flow error	The accumulated flow has exceeded the accumulated flow range.	Reset the accumulated flow.	_	•
c HHH	Over upper limit of temperature	Fluid temperature exceeds 110°C.	Lower the fluid temperature.	•	•
c LLL	Under lower limit of temperature	Fluid temperature is under –10°C.	Raise the fluid temperature.	•	•
Er O			Turn the power OFF and turn it ON again.		
Er 4	System error	An internal data error has occurred.			
Er B	System end	All internal data entir has occurred.			
Er 8					
Er 7	Custom surer	An internal data error has occurred.	Turn the power OFF and turn it ON again.		
Er 40	System error				
Er 12	Temperature sensor failure	Temperature sensor may be damaged.	Turn the power OFF and turn it ON again.	•	•
Er 15	Version does not match	The IO-Link version does not match that of the master. The master uses version 1.0.	Ensure that the master IO-Link version matches the device version.	_	•

If the error cannot be solved after the instructions above are performed, please contact SMC for investigation.

Remote Sensor Unit: PF3W5 Series

■ POWER indicator function


It is possible to check whether power supply is reaching the product. When power is supplied to the product, the indicator lights up green.

■ FLOW indicator function

Status of the flow rate can be checked visually. When the flow rate increases, the green indicator light blinks faster. When below the measurable lower limit of flow rate, the indicator light turns off, when above the measurable upper limit of flow rate, red indicator light turns on.

■ Error display function

When an error or abnormality arises, the location and contents are displayed.




LED display		Description	Contents	Action
POWER Red	Red FLOW POWER indicator: Red ON FLOW indicator: Red ON		Internal data error or other errors occur.	Turn the power off and then on again. If the error cannot be rectified, please contact SMC for in-
POWER Red	Red FLOW POWER indicator: Red ON FLOW indicator: Blinking red	System error		
POWER Red	FLOW POWER indicator: Red ON FLOW indicator: OFF		Temperature sensor may be damaged.	vestigation.

If the error cannot be solved after the above instructions are performed, please contact SMC for investigation.



PF3WB/C/S/R Series Reference Data


[Reference] Flow Characteristics of the Entire System





- * Flow characteristics when the unit consists of sensors of the same structure
- * When the unit includes the flow adjustment valve and stop valve, they are fully open.
- * The flow characteristics for multiple supply units is based on the flow coming from the main piping (supply (IN)) to each supply unit (supply (OUT)).
- * The flow characteristics for multiple return units is based on the flow coming from each return unit (return (IN)) to the main piping (return (OUT)).
- * Assuming constant flow to each unit

■ Flow characteristics for multiple supply units

Flow range: 0.5 to 4 L/min (Symbol 04) (Reference value)









Flow range: 2 to 16 L/min (Symbol 20) (Reference value)


Unit components: Nil








Unit components: P




Unit components: W




Flow range: 5 to 40 L/min (Symbol 40) (Reference value)


Unit components: Nil




Unit components: S



Unit components: P



Unit components: W




[Reference] Flow Characteristics of the Entire System


■ Characteristics of total flow for multiple return units

Flow range: 0.5 to 4 L/min (Symbol 04) (Reference value)


Unit components: Nil




Unit components: S



Unit components: P




Unit components: W




Flow range: 2 to 16 L/min (Symbol 20) (Reference value)


Unit components: Nil




Unit components: S



Unit components: P




Unit components: W




Flow range: 5 to 40 L/min (Symbol 40) (Reference value)


Unit components: Nil




Unit components: S



Unit components: P



Unit components: W



⚠ Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "Caution," "Warning" or "Danger." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)*1), and other safety regulations.

Caution: Caution indicates a hazard with a low level of risk which, If not avoided, could result in minor or moderate injury.

Warning: Warning indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.

⚠ Danger: Danger indicates a nazaru wiun a nigin level on the first avoided, will result in death or serious injury. **Danger** indicates a hazard with a high level of risk which, *1) ISO 4414: Pneumatic fluid power - General rules relating to systems.

ISO 4413: Hydraulic fluid power – General rules relating to systems.

IEC 60204-1: Safety of machinery - Electrical equipment of machines. (Part 1: General requirements)

ISO 10218-1: Manipulating industrial robots - Safety.

⚠ Warning

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalog information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

- 3. Do not service or attempt to remove product and machinery/ equipment until safety is confirmed.
 - 1. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
 - 2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
 - 3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.
- 4. Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following conditions.
 - 1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
 - 2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalog.
 - 3. An application which could have negative effects on people, property, or animals requiring special safety analysis.
 - 4. Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation.

⚠ Caution

1. The product is provided for use in manufacturing industries.

The product herein described is basically provided for peaceful use in manufacturing industries.

If considering using the product in other industries, consult SMC beforehand and exchange specifications or a contract if necessary.

If anything is unclear, contact your nearest sales branch.

Limited warranty and Disclaimer/ **Compliance Requirements**

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".

Read and accept them before using the product.

Limited warranty and Disclaimer

- 1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, whichever is first.*2) Also, the product may have specified durability, running distance or
- replacement parts. Please consult your nearest sales branch. 2. For any failure or damage reported within the warranty period which is clearly our
- responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- 3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalog for the particular products.
 - 2) Vacuum pads are excluded from this 1 year warranty.

A vacuum pad is a consumable part, so it is warranted for a year after it is delivered.

Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

Compliance Requirements

- 1. The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
- 2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

⚠ Caution

SMC products are not intended for use as instruments for legal metrology.

Measurement instruments that SMC manufactures or sells have not been qualified by type approval tests relevant to the metrology (measurement) laws of each country. Therefore, SMC products cannot be used for business or certification ordained by the metrology (measurement) laws of each country.